

SWIM FINS | SHORT BLADE FINS | SIZING CHART

How to select your correct size


FIN SIZE CHART			A	B	C	D
Australian Sizing	European Sizing	USA Sizing	Length of Foot Pocket	Width of Foot Pocket at Widest	Length of Foot Pocket Opening	Width of Foot Pocket Opening
6-8	26/29	0-0	19.0cm	7.0cm	7.5cm	4.5cm
8-11	30/33	0-1	19.0cm	7.2cm	8.0cm	5.0cm
11-1	34/35	1-3	20.0cm	7.5cm	8.0cm	5.5cm
1-3	36/37	3-5	21.0cm	8.0cm	8.5cm	5.5cm
3-5	38/39	5-7	22.0cm	8.5cm	9.0cm	6.0cm
5-7	40/41	7-9	23.0cm	9.0cm	9.5cm	6.5cm
7-9	42/43	9-11	25.0 cm	9.5cm	10.0cm	7.0cm
9-11	44/45	11-13	26.0cm	10.0cm	11.0cm	7.5cm
11-13	46/48	14-15	27.0cm	10.5cm	11.5cm	8.0cm
13-15	49/51	16-17	29.0cm	11.0cm	12.0cm	8.0cm
15-17	51/53	17-18	30.0cm	11.0cm	13.0cm	8.0cm
17-19	53/55	19-20	31.5cm	11.7cm	14.0cm	9.0cm

Notes

1. Eyeline uses only Australian Sizing as its reference sizing.
2. Sizes shown in above chart are male sizes.
3. For female sizing we suggest you select 1 size down, for example a female 7-9 size equals a male 5-7 size.

Care for your fins

1. Avoid prolonged exposure to direct sunlight.
2. Don't leave near a heat source.
3. Rinse in fresh water after each use.
4. Never expose to chemicals or solvents.
5. To give them a good clean ONLY use mild soap and water or a rubber cleaner/preservative.



SWIM FIN CARE

How to care for your swim fins

The majority of damage to swim fins occurs when placing fins on your feet or when walking. It is important that you read through the following procedures to reduce the likelihood of damage and maximize the life of your purchase.


WARNING!

DO NOT walk in swim fins as you would normally 'heel and toe' as this may crack the side rails and void your warranty.


It is BEST to wet both the fins and feet when putting on.

It is BEST to put fins on at the pool edge or the water's edge if using in the surf.

ADVICE: Swim fins are made to aid swimming and NOT for general walking.




Fitting your fins correctly



Step A: Place three fingers inside each side of the foot pocket and your thumbs in the centre base of the heel pocket and fold back.



Step B: If done correctly, your fin will look like this.



Step C: Slide foot into fin as far as possible. **It is best to have both the fin and foot wet as it will make fitting a lot easier. Repeat for other foot.**



Step D: When foot is fully inserted and comfortable, roll the back of the pocket up and around the heel.




Warning: Never grab the front section of the foot pocket and attempt to pull fins onto your feet. More than likely you will tear the rubber at each side of the toe area.

This action will void your warranty.




Warning: Never try to pull on the fins by the back of the foot pocket. More than likely you will tear the foot pocket. **This action will void your warranty.**

Correct walking action helps prevent damage to your fins



Walking A: Walk backwards or forwards in short steps. Keep both feet parallel to the ground. Do not scuff or bend the blades whilst walking.



Walking B: It is a lot easier to walk backwards with your fins on. Keep both feet parallel to the ground, and lift each foot completely off the ground in the walking action. Be very careful when walking backwards to avoid any chance of tripping.



Warning: DO NOT use the fins to support your weight in the water. For children, when seated, don't allow them to 'over-bend' the fin blades. Either of these actions may cause the fin blade to crack in the rail section.

This action will void your warranty.